

How Do I Connect a DRC-32/DRC-1 or DS32 to a TRip unit.

Here are the lead manufacturing details.

DRC-32 / DRC-1 to TRip

DRC-32/ DRC-1		Trip Connections	
Pin 1	Line In 0	Pin 3	Line Out 0
2	Line In 1	6	Line Out 1
3	Line Out 0	4	Line In 0
4	TX Data	1	RX Data
5	RX Data	2	TX Data
6	Line Out 1	5	Line In 1
7	PTT	7	NC
8	Ground	8	Ground

DS-32 to TRip

DS-32 Port		TRIP	
PIN 1	Line Out 0	PIN 4	Line In 0
2	Line Out 1	5	Line In 1
3	Line In 0	3	Line Out 0
4	RX Data	2	TX Data
5	TX Data	1	RX Data
6	Line In 1	6	Line Out 1
7	PTT	7	NC
8	Ground	8	Ground

PTT is not required for DS-32 – DRC-32 connection.

Document
TRIP interconnection
July 23rd 2007
GJB